



Care and Cleaning Instructions for these Waterstone Finishes:

PG (Polished Gold)

SG (Satin Gold)

About Your Finish

This finish is done with real precious metal gold plating on the brass fixture surface. This finish has **NO PROTECTIVE COATINGS and is extremely soft**. Some or all of the Gold plating will be removed if any type of polish is used. Additionally, the finish will wear away with time. The gold plating is considered very delicate and can be easily scratched or scuffed. Any type of astringent cleaner or any type of abrasive cleanser, pad, cloth or sponge will damage the finish.

IMPORTANT NOTICE:

*It is the responsibility of the customer to check for any material finish defects **before** installation.
Waterstone does not warranty these finishes **after** the fixture has been installed.*

Suggested Finish Maintenance Procedures

1. Do not allow water spots to dry on the fixture. Keep the finish surface clean and dry after use.
2. Periodic cleaning can be done with mild liquid soap only. Wipe gently with a soft cloth to clean.
3. Never use cleaners with abrasives, soft scrub, Clorox, any type of abrasive pad or sponge.

